



Installation Instructions Weather Station

Anemometer, Pyranometer, & Temperature/Humidity

Hillsboro, OR USA

(503) 601-2099

Fax (503) 601-6878

1-866-204-8134

<http://www.obvius.com>

email:sales@obvius.com



Revised 07-29-2010

Copyright Information

Copyright © 2007 - 2008 by Obvius

Obvius, AcquiSuite and ModHopper are trademarks of Obvius Holdings LLc

Other brand and product names are trademarks or registered trademarks of their respective holders.

U.S. Government Restricted Rights: Use, duplication or disclosure by the Government is subject to restrictions set fourth in subparagraph (a) through (d) of the Commercial Computer Restricted Rights clause at FAR 52.227-19 when applicable, or subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013, and in similar clauses in the NASA FAR Supplement.

Limited Warranty

OBVIUS IS PROVIDING THIS WARRANTY IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THIS WARRANTY IS BUYER'S EXCLUSIVE REMEDY FOR ALL CLAIMS AGAINST OBVIUS. OBVIUS SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES. OBVIUS'S TOTAL LIABILITY FOR ALL CLAIMS SHALL BE LIMITED TO THE PRICE PAID FOR ITS PRODUCT.

Obvius promises buyer that any standard product manufactured by Obvius shall be free from all material defects in design, material, or manufacturing for a period of 2 years from the manufacture date; provided, however, that the warranty shall not extend to ordinary wear and tear or to normally replaceable components (e.g., batteries). During the warranty period, Obvius may repair or replace (in its sole discretion) any product suffering from a warranty defect and returned freight prepaid by buyer, with no charge to buyer for any warranty repair or replacement. The warranty shall remain in full force and effect for such 2 year period, provided that the product: (1) was installed, operated, and maintained properly; (2) has not been abused or misused; (3) has not been repaired, altered, or modified outside of Obvius's authorized facilities; (4) has not been sold subject to other warranty terms specified at the time of sale; and (5) is still owned by the original purchaser. This warranty provides specific legal rights that may be varied by state law. Obvius's products are not designed for life or safety applications.

Product Application Limitation

Obvius strongly believes in continuous improvement, therefore we must reserve the right to change specifications and product offerings without notice. Where possible, we will substitute products with equivalent functionality when necessary.

DANGER

Hazard of Electric Shock, Explosion or Arc Flash

- Follow safe electrical work practices. See NFPA 70E in the USA, or applicable local codes.
- This equipment must only be installed and serviced by qualified electrical personnel.
- Read, understand and follow the instructions before installing this product.
- Turn off all power supplying equipment before working on or inside the equipment. Use properly rated voltage sensing device to confirm power is off. DO NOT DEPEND ON THIS PRODUCT FOR VOLTAGE INDICATION
- Only install this product on insulated conductors.

Failure to follow these instructions will result in death or serious injury.

NOTICE

- This product is not intended for life safety applications.
- Do not install this product in hazardous or classified locations.
- The installer is responsible for conformance to all applicable codes.
- Mount this product inside a suitable fire and electrical enclosure.

FCC Part 15 Information

Note: This equipment has been tested by the manufacturer and found to comply with the limits of a class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. Modifications of this product without the express authorization of Obvius nullify this statement.

Easy Installation

- Simple U-bolt attachments makes for quick and easy installation
- Comes with pre-wired weather resistant enclosure, making attachment of sensors both simple and straightforward
- Easy to use quick connect plugs allow for seamless integration into the AcquiSuite network

Applications

- Solar Applications- Inverters, Solar Current Monitors...etc
- Processes dependent on external weather conditions
- Monitoring performance of building systems when used in conjunction with Acquisuite (e.g., chillers, boilers, fans)

Operation

The Weather Station is a weather sensing device designed to monitor varying meteorological conditions. Designed specifically for solar applications, the Weather Station provides efficiency verifications for photovoltaic cells, by allowing users to chart and note varying meteorological conditions and the particular effect each has on solar DC power generation. For instance, the introduction of rain to solar arrays can minimize production as a result of both associated cloud cover and water accumulation on the cells themselves. For a more direct comparative measure, the pyranometer works in a similar fashion as the solar arrays themselves, generating a number representative of solar radiation per square meter.

The standard Weather Station A89WSW includes the following:

- Weather resistant Nema 6P/12 enclosure w/panel
- One I/O Module (Built-In)
- One Mast and Tri-pod
- Four U-bolt mast attachments
- One metal support arm
- Temperature and Humidity Sensor (Analog x 2)
- Wind Speed and Direction (Analog x 2)
- Pyranometer (Analog)

Optional Weather Station attachments:

- Temperature Sensor (Analog)
- Cell Temperature Probe (Analog)

The Weather Station is a rather flexible and scalable product in terms of the possible mix of sensor configurations; thus, making it a customizable product allowing for adaptation to almost any environmental application. Most applications dependent on external weather conditions can use the weather station for both measurement and verification of processes.

Location


As there are many variables which could affect the accuracy of the Weather Station's readings, there are certain things to take into consideration when installing. Use the following as a guide for factory recommended assembly:

- Ensure that the device is located in as open and unobstructed area as possible (i.e. roofs). Each of the sensors requires certain directional and spatial alignments when installing.
- As the Pyranometer records solar radiance, the main concern during installation is an unobstructed view of the sky; this means to avoid bushes, trees, or other objects which might cast a shadow over the sensor effectively limiting the validity of the readings.
- The Temperature and Humidity sensors must be installed inverted, with the protruding tube pointing down. Also to avoid direct contact with the thermal variances caused by the sun, place the sensor in a Northerly direction.
- Other thermal variances can be caused by exhaust from other mechanical equipment, thus the device should be spaced accordingly.
- As for the Wind Direction and Speed sensors, the main concern is an area that allows for free flowing air circulation. Often this is attained by locating the device on the highest possible location, and if not available, ensuring that the distance from such obstructions is maximized. As a general rule, air flow around a structure is distributed to twice the height of the structure upwind, six times the height downwind, and up to twice the height of the structure above ground.

Installation

Mast and Tri-pod assembly (See diagram below)

- 1) Remove tri-pod and antenna from packaging
- 2) Expand tri-pod legs and insert antenna mast through hole at the top and secure using nuts and bolts attached to tri-pod



(Use ½" Wrench to secure inner nut while tightening)

- 3) Place NEMA enclosures flush against the antenna mast, with the bottom resting on the top supports of the tri-pods legs. Secure the top using one of the four U-bolts provided, tighten to ensure stability
- 4) Attach the support arm directly above the weatherstation enclosure using two of the U-bolts provided.
- 5) Remove the Temperature/Temperature and humidity device and using screws and bolts provided, attach the device in an inverted position to the longest of the adjacent sides of the support arm.
- 6) (SEE ARM DIAGRAM BELOW FOR REFERENCE) Approximately 5” from the top of the enclosure is the optimum placement for the bottom of the support arm. Use the other two U-bolts provided to secure the arm directly to the mast via the longer of the adjacent sides (the same side the temperature sensor is attached to, only mounted internally within the enclosure)
- 7) Next attach the Pyranometer to the top of the support arm, assuring alignment with the three mounting holes on the arm and the sensor itself. Attach using bolts and nuts provided
- 8) The final step for installation is simply placing the wind direction and speed sensor over the top of the mast, using attached fastening screws to secure.




Configuration

- 1) It is important that each Modbus device on a single network must have a unique address before the device is connected to the Modbus RS485 network.
- 2) In the case of the Weather Station, the I/O modules come preconfigured with a Modbus address of 51 and 52 if a second module is needed. As these are somewhat unique addresses there should be little if any instances where a change in addressing is needed. If however Modbus addresses 51 or 52 are already in use, follow step 3 below for alteration.
- 3) The Modbus address given is important to remember as this is the way to initially identify the device via the master. Therefore use the following guide for altering the addresses via a dip switch:

The Dip Switches are activated by moving them into the ON position as noted on the devices. The sum of the value of the dipswitches is the address. In the below examples Modbus address 1 is set by simply turning switch 1 to the ON position, whereas Modbus address 40 is set by placing switch 4 and 6 to the ON position.


The values of each dip switch are as follows:

- 1=1
- 2=2
- 3=4
- 4=8
- 5=16
- 6=32
- 7=64
- 8=128




To determine an address you simply add the values of any switch that is on.

For example:



Switch number 4 has an ON Value of 8 and switch number 6 has an ON Value of 32. (8+32 = 40)

ADDRESS SELECTION EXAMPLES



- 4) The following are the default factory settings for the Modhoppers:
- Modbus Address Dip Switch 1,3,6, and 7 ON
 - Modbus Address Dip Switch 2,4,5, and 8 OFF
 - Modbus Channel 1,2, and 3 OFF -Channel 0 (If integrating with an existing Modhopper subsystem ensure that both devices are on the same channel to ensure communication).
 - All other dipswitches should be left in the off position

The A8332-8F2D module only has 7 dipswitches which allow up to 128 possible Modbus addresses.

Wiring Instructions

The devices within (I/O and Power Supply) come pre wired and configured. The installer will need to attach the sensors and power supply, and modify the Modbus addressing as described in the Installations section above.

Note: the plugs attached to each of the sensors. These plugs only fit into one of the receptacles on the enclosure eliminating the possibility of incorrect wiring. See the below diagram showing the internal wiring of the enclosure. Users should only have to access the inside of the enclosure when first providing power and running communication lines back to the AcquiSuite.

I/O-51

IN1- Wind Speed

IN2- Wind Direction

IN3- Temperature (Orange)

IN4- Humidity (Blue)

IN5- Pyranometer

IN6-Cell Temperature (optional)

Internal Wiring

Wind Speed & Direction-

The Wind Speed & Direction Sensor connects to the field wireable 6 pin connector on the bottom left of the nema enclosure.

Temperature/ Temperature & Humidity-

The Temperature/ Temperature & Humidity sensors share the same field wireable 4 pin connector located on the bottom right of the enclosure.



Weather
Proof
Screw
Cap



Weather
Proof
Gasket


Pyranometer- Solar Irradiance-

The Pyranometer sensor connects to the field wireable 4 pin connector located at the bottom middle of the enclosure.



Internal Wiring

No power cable is provided for providing power to the weather station. To power the device, the user needs to supply the device with a 110-120VAC



The Weather Station communicates internally with an RS485 Modbus RTU loop, to bring communication back to a wireless device such as the Modhopper or to an AcquiSuite, simply connect the RS485 + and RS485 – on the IO module (shown above upper right) to the RS485 + and RS485 – of the mating device.

Alignment

The Wind Speed & Direction and Pyranometer both require slight aligning to ensure proper readings.

Wind Speed & Direction Alignment-

Align the front of the wind vane (the propellers) facing direct north. Rotate the base of the sensor, keeping the vane aligned northerly, until the values are reading close to north which is approximately 360 degrees/0 degrees (A 5 degree variance will suffice for most applications... i.e. 355-360 degrees or 0-5 degrees). As a reference point, for alignment purposes there is a sticker on the sensor labeled North, ensure this is faced in a northerly direction.

Pyranometer Alignment-

Once removed from packaging, note the built in leveling system attached to the device. This allows you to ensure the device is level to ensure proper sun exposure. After mounted to the arm support, use the adjustment screws to level the device. A Pyranometer is level when the bubble is in the center, or as close as possible, of the leveling gauge.

Configuration and Scaling

When using the Acquisuite as a master Modbus device, the following configurations can be entered by accessing the Acquisuite directly then proceeding to select the device, in this case the I/O module in question. Click on the 'configure' button at the bottom of the page, once the page refreshes select the option 'Config Point', this will allow you to enter the following values for each device.

Wind Direction

Min Range 0

Max Range 360

Make and Model as Custom

Preconfigured Units as Custom

Engineering units Degrees

(for your use only, not to be entered on the Acquisuite)

Azimuth: 360° mechanical, 355° electrical (5° open)

360°/0°=North 90°=East 180°=South 270°=West

Wind Speed

Min Range 0

Max Range 100

Make and Model as Custom

Preconfigured Units as Custom

Engineering units MPH

(for your use only, not to be entered on the Acquisuite)

Gusts up to 220 MPH

Temperature

Min Range -40

Max Range 122

Preconfigured Units as Custom

Engineering units Degrees F

Humidity

Min Range 0

Max Range 100

Make and Model as HW Humidity

Preconfigured Units as Custom

Engineering Units %RH

Veris Cell Temperature Probe

Input Mode as Resistance

Make and Model as Custom

Curve Scale select Veris 10K Type 2 (ohms → degrees F)

Engineering Units Degrees F

Pyranometer

Min Range 0

Max Range See below for calculation

Make and Model as Custom

Preconfigured Units as Custom

Engineering Units Watts

Pyranometer Max Range:

1. Locate the Certificate of Calibration form provided with the Pyranometer and note the multiplier (Circled below in red)

Pyranometer Model Number: LI-200	
Serial Number: PY00000	Calibration Date: April Manufacture Date: April
Calibration Constant:	
Output: 88.31 microamps per 1000 watts m ⁻²	
For use with LI-COR handheld meters:	
Multiplier: -11.32 watts m ⁻² per microamp	

Sample Li-Cor Certificate of Calibration

2. Multiply the Multiplier by 125, and the result is the Maximum Range for that particular Pyranometer (see example below)

Maximum Light Level = 125 * LICOR Multiplier

Example

LICOR Multiplier = -11.33 watts m²/μA

Maximum Light Level = 125 * 11.33

Maximum Light Level = 1,416.25 watts m²

Powering the station

As previously discussed there is no power cord included for providing external power to the devices. Therefore the user has two options for powering the device. The first option is to install a power transformer as seen in the pictures above, in which case all the user will be required to do is provide 110-120VAC using a power cable rated for outdoor conditions to the transformer directly. The second option is to utilize a terminal strip, in which case the user would need to provide 24VDC to the strip, supplying the necessary voltage to the respective devices.

Recommended Maintenance of third party devices

Some of the sensors utilized in the Weather Station require either replacement or re-calibration after deployment.

Li-Cor recommends the LI-200SZ Pyranometers be calibrated every two years to maintain the sensor accuracy. This requires the device to be sent back to Li-Cor (402) 467-3576 for recalibration.

Veris recommends the humidity element on the HO2XMSTA1-O2 Temperature/Humidity sensors be tested every year and replaced accordingly. This element is field replaceable, and can be obtained by contacting Veris Industries (503) 598-4564 directly.

Modbus Register Listing – A8332-8F2D

Data points:

Offset	point	type	desc	modes-->	Pulse	Status	Ohms,	mA,	volts
0	40001	UINT32	input 1	value MSW	(count/NV,	count/NV,	inst,	inst,	inst)
1	40002	UINT32	input 1	value LSW					
2	40003	UINT32	input 2	value MSW	(count/NV,	count/NV,	inst,	inst,	inst)
3	40004	UINT32	input 2	value LSW					
4	40005	UINT32	input 3	value MSW	(count/NV,	count/NV,	inst,	inst,	inst)
5	40006	UINT32	input 3	value LSW					
6	40007	UINT32	input 4	value MSW	(count/NV,	count/NV,	inst,	inst,	inst)
7	40008	UINT32	input 4	value LSW					
8	40009	UINT32	input 5	value MSW	(count/NV,	count/NV,	inst,	inst,	inst)
9	40010	UINT32	input 5	value LSW					
10	40011	UINT32	input 6	value MSW	(count/NV,	count/NV,	inst,	inst,	inst)
11	40012	UINT32	input 6	value LSW					
12	40013	UINT32	input 7	value MSW	(count/NV,	count/NV,	inst,	inst,	inst)
13	40014	UINT32	input 7	value LSW					
14	40015	UINT32	input 8	value MSW	(count/NV,	count/NV,	inst,	inst,	inst)
15	40016	UINT32	input 8	value LSW					
modes-->					Pulse	Status	Ohms,	mA,	volts
16	40017	UINT32	input 1	ave MSW	(rate-inst,	on-time/NV,	ave,	ave,	ave)
17	40018	UINT32	input 1	ave LSW					
18	40019	UINT32	input 2	ave MSW	(rate-inst,	on-time/NV,	ave,	ave,	ave)
19	40020	UINT32	input 2	ave LSW					
20	40021	UINT32	input 3	ave MSW	(rate-inst,	on-time/NV,	ave,	ave,	ave)

21	40022	UINT32	input 3	ave LSW					
22	40023	UINT32	input 4	ave MSW	(rate-inst,	on-time/NV,	ave,	ave,	ave)
23	40024	UINT32	input 4	ave LSW					
24	40025	UINT32	input 5	ave MSW	(rate-inst,	on-time/NV,	ave,	ave,	ave)
25	40026	UINT32	input 5	ave LSW					
26	40027	UINT32	input 6	ave MSW	(rate-inst,	on-time/NV,	ave,	ave,	ave)
27	40028	UINT32	input 6	ave LSW					
28	40029	UINT32	input 7	ave MSW	(rate-inst,	on-time/NV,	ave,	ave,	ave)
29	40030	UINT32	input 7	ave LSW					
30	40031	UINT32	input 8	ave MSW	(rate-inst,	on-time/NV,	ave,	ave,	ave)
31	40032	UINT32	input 8	ave LSW					

modes-->					Pulse	Status	Ohms,	mA,	volts
32	40033	UINT32	input 1	min MSW	(rate-min,	dutycycle,	min,	min,	min)
33	40034	UINT32	input 1	min LSW					
34	40035	UINT32	input 2	min MSW	(rate-min,	dutycycle,	min,	min,	min)
35	40036	UINT32	input 2	min LSW					
36	40037	UINT32	input 3	min MSW	(rate-min,	dutycycle,	min,	min,	min)
37	40038	UINT32	input 3	min LSW					
38	40039	UINT32	input 4	min MSW	(rate-min,	dutycycle,	min,	min,	min)
39	40040	UINT32	input 4	min LSW					
40	40041	UINT32	input 5	min MSW	(rate-min,	dutycycle,	min,	min,	min)
41	40042	UINT32	input 5	min LSW					
42	40043	UINT32	input 6	min MSW	(rate-min,	dutycycle,	min,	min,	min)
43	40044	UINT32	input 6	min LSW					
44	40045	UINT32	input 7	min MSW	(rate-min,	dutycycle,	min,	min,	min)
45	40046	UINT32	input 7	min LSW					
46	40047	UINT32	input 8	min MSW	(rate-min,	dutycycle,	min,	min,	min)
47	40048	UINT32	input 8	min LSW					

modes-->					Pulse	Status	Ohms,	mA,	volts
48	40049	UINT32	input 1	max MSW	(rate-max,	status	max,	max,	max)
49	40050	UINT32	input 1	max LSW					
50	40051	UINT32	input 2	max MSW	(rate-max,	status	max,	max,	max)
51	40052	UINT32	input 2	max LSW					
52	40053	UINT32	input 3	max MSW	(rate-max,	status	max,	max,	max)
53	40054	UINT32	input 3	max LSW					
54	40055	UINT32	input 4	max MSW	(rate-max,	status	max,	max,	max)
55	40056	UINT32	input 4	max LSW					
56	40057	UINT32	input 5	max MSW	(rate-max,	status	max,	max,	max)
57	40058	UINT32	input 5	max LSW					
58	40059	UINT32	input 6	max MSW	(rate-max,	status	max,	max,	max)
59	40060	UINT32	input 6	max LSW					
60	40061	UINT32	input 7	max MSW	(rate-max,	status	max,	max,	max)
61	40062	UINT32	input 7	max LSW					
62	40063	UINT32	input 8	max MSW	(rate-max,	status	max,	max,	max)
63	40064	UINT32	input 8	max LSW					

Mode setting options. see above for value details.

64	40065	UINT16	input 1	mode	(NV/r/w)				
65	40066	UINT16	input 2	mode	(NV/r/w)				
66	40067	UINT16	input 3	mode	(NV/r/w)				
67	40068	UINT16	input 4	mode	(NV/r/w)				
68	40069	UINT16	input 5	mode	(NV/r/w)				
69	40070	UINT16	input 6	mode	(NV/r/w)				
70	40071	UINT16	input 7	mode	(NV/r/w)				

71	40072	UINT16	input 8 mode (NV/r/w)
72	40073	UINT16	input status bitmap. (pulse/status modes only)
73	40074	UINT16	input broken wire alarm bitmap. (resistance, current modes only) Restive mode: bit set when resistance is off-scale-high. 4-20mA mode: bit is set when current is below 4mA.
74	40075	UINT16	relay output 1 (r/w) 0=open, 1=closed, defaults to open on power-up. r/w allowed when register 41030 = 0.
75	40076	UINT16	relay output 2 (r/w) 0=open, 1=closed
--- system settings and information ---			
999	41000	UINT16	contact closure threshold (NV/r/w) in ohms, default 1000 = 1kohm. (minimum value 100 ohms, maximum value 5000 ohms)
1000	41001	UINT16	contact open wire threshold (NV/r/w) in ohms, default/unused = 0xFFFF, limit 100 to 10,000 ohms.
1001	41002	UINT16	number of pulses for inst rate (NV/r/w) default 5. limit 2 to 20.
1002	41003	UINT16	serial number bytes 1,2
1003	41004	UINT16	serial number bytes 3,4
1004	41005	UINT16	serial number bytes 5,6
1005	41006	UINT16	firmware version (major)
1006	41007	UINT16	firmware version (minor)
1007	41008	UINT32	Reserved
1008	41009	UINT32	Reserved
1009	41010	INT16	Reserved
1010	41011	INT16	Reserved
1011	41012	UINT32	uptime MSW number of seconds since IO module booted.
1012	41013	UINT32	uptime LSW
1013	41014	UINT16	hardware version (major) for example: 8332
1014	41015	UINT16	hardware version (minor) MSB = pcb rev, LSB = part rev. value 1=Rev_A, 2=Rev_B, etc.
1015	41016	UINT32	hardware Date of Manufacture (MSW)
1016	41017	UINT32	hardware Date of Manufacture (LSW) time, UTC, unix epoch, seconds past 1970.
1017	41018	UINT16	RS485 Stats: Good RX (all packets received)
1018	41019	UINT16	RS485 Stats: Total TX
1019	41020	UINT16	RS485 Stats: TX failed
1020	41021	UINT16	clear min/max/ave (r/w) read returns 0, write any value to clear min/max/ave for all channels.
1021	41022	UINT8	reserved
1022	41023	UINT8	reserved
1023	41024	UINT8	reserved
1024	41025	UINT8	reason for reboot. 0x01=POR, 0x02=EXTR 0x04=WDTR 0x08=BODR, 0x8000=WDTOF
1025	41026	UINT16	power supply voltage monitor. scale: x100, volts
1026	41027	INT16	pcb temperature monitor. scale: x100, degrees F.
1027	41028	UINT16	5V internal power supply voltage monitor. scale: x100, volts

